

# HADLEY PRODUCTS


## INSTALLATION INSTRUCTIONS FOR CHECK VALVE

Using this check valve will provide an additional seal to maintain air tank pressure.

**CAUTION:** DO NOT MOUNT CHECK VALVE IN COMPRESSOR HEAD, OR UNIT WILL NOT OPERATE PROPERLY.

### INSTRUCTIONS

1. Disconnect compressor air line from tank assembly.
2. Remove brass fitting #H12553 from current location.
3. Install brass check valve provided. Add pipe sealant to threads if check valve was not supplied with it.
4. Re-connect airline to check valve.



If you should have any questions about this installation, please contact the service department at Hadley Products. Service Direct Line (616)-249-8462

Hadley Products  
2851 Prairie S.W. Suite D  
Grandville, MI 49418  
Main: (616) 530-1717  
Fax: (616) 530-3283



[www.hadley-products.com](http://www.hadley-products.com)

Page 1 Rev: A/99  
Filename: 15452.p65